

Hydrant Flushing Zones

Flushing Zones

- 1
- 2
- 3
- 4
- 5

3
April 29 - May 10

2
April 15 - April 26

1
April 1 - April 12

4
May 13 - May 24

5
May 28 - June 7



Updated: 3/31/2021

